



OUTFITTER CAMP KITCHEN XL

Directions for Assembly

1. Assemble the shelves

- Remove Velcro and attach to back leg when set up complete.
- Insert legs into top of bottom shelf, ensuring the narrow part of leg faces down. Legs marked "B2" should be used in the back of stage 2. Slide stage 2 shelf onto legs. Repeat for second shelf, again ensuring "B2" legs are inserted in the rear of stage 2. Slide sink base onto legs. Insert leg caps into front leg holes.
- Insert 5.5' poles into back leg holes with "T" facing up. Insert cross bar thru "T's" as shown. Rotate end elbows.
- Drain basins and sinks can be inserted now.
- Do not assemble spigot yet. This will be done in step 2a. Shelves are complete.

2. Assemble Water Filtration and Pump

- Stack buckets with 2 hole bucket on bottom, next, the smaller bucket, with the filtering bucket on top. Insert Sawyer Water Filter with hose on top bucket with arrow facing down. Insert bottom tube into 2 hole bucket. Weave pump tube thru foot pedal making sure siphon sits between dowel rods. Insert tube thru bottom of sink base at the rear, carefully threading thru spigot. Spigot may need to be partially disassembled to work its way thru elbows. Place lids on buckets to protect water from insect or debris infiltration.

3. Use

- Fill top bucket with water 2/3 full. If using water from a lake or stream it is best to strain water thru a t-shirt, strainer or coffee filter to prevent Sawyer Water Filter from clogging prematurely. If water moves slowly thru filter, it may be necessary to prime the filter. The easiest method for this would be to suck on the bottom tube from the filter. The water will be clean, so you needn't be concerned about dirt, bacteria or viruses. The water should now flow freely thru the filter into the 2 hole bucket. It will take time to get enough water thru the 2 hole bucket, so be patient....Venice wasn't flooded in a day, you know.

Useful tips

The elbows on the hanging rack are ideal for hanging lanterns or hats. Paper towels will fit right onto the crossbar of the hanging rack. The center bucket with lid can be used to store clean towels, soap or sponges. The Sawyer Water Filter will need to be flushed from time to time. Inside the kit you will find syringe and instructions for doing so. The Sawyer Water Filter should not be left outside during freezing temperatures. If the kitchen cannot be moved indoors, in freezing temperatures boiling water may be



By Prepper's Landing. All images and content are copyright protected. Please do not use without prior permission. If you want to republish this page, please re-write the information in your own words, or simply link back to this post for the information. Thank you muchly.



Copyright